TOOLBOX OR ART CADDY

Materials and Tools

- ➤ Five 1-by-6-inch pieces of wood to be cut to various lengths
- ► Broomstick piece or dowel, 18 inches long, for the handle
- ▶ Wood screws
- ► Wood glue
- ► Hand saw
- ▶ Brace and bit
- ▶ Screwdriver
- ▶ Measuring tape





Instructions

- 1. Cut two pieces of wood 17½ inches long for the two long sides.
- 2. Cut one piece of wood 16 inches long for the bottom.
- 3. Cut two pieces of wood 10 inches long for the ends.
- 4. Cut off the corners of the end pieces at an angle, then drill a hole in each large enough for the handle. The center of each hole should be 1¾ inch from the top and centered between the edges of the piece.
- 5. Insert the handle. Then, put your toolbox together with wood screws. If you wish, you may put wood glue on the joints and let it dry before using the wood screws.
- 6. Decorate or finish your toolbox using stain or paint.





